




ISN-GMX-S1 Test Transmitter



Mounts under ISN-SM Series Seismic Detectors, directly on the mounting plate or on the supervised surface. The mechanical oscillations from the test transmitter are propagated in the surface as vibrations. The seismic detector picks up the vibration signals and triggers an alarm if the detector is functioning correctly. This tests not only the detector itself, but also the physical contact between the detector and the protected object.

Ordering Information

ISN-GMX-S1 Test Transmitter

Mounts under a seismic detector. Tests the detector and the physical contact between the detector and protected object.

ISN-GMX-S1